Computer Bits

SOFTWARE TOOLS

O MATTER how small the computer, even the most dedicated programmer will rapidly become bored with binary notation.

Some hobbyists use a Teletype as there are several older models on the market at reasonable prices. Even with a Teletype, though, you need some software to convert those keystrokes into something meaningful in memory. If you can't afford a Teletype, you can almost always use an en-

By Jerry Ogdin

coded keyboard. These are frequently on the surplus market for less than \$25.00.

A terminal is important, but it is only one tool in the computer hobbyist's kit. Once you've written a program and gotten it into storage, you ought to use the cassette interface (HIT) described in September's column. With this tool, you have to "button in" the program bit-by-bit only once. After it is in storage, you can write it out to be taped

and read in the next time you want it. Of course, if your only storage medium is RAM, you'll lose the memory contents when you turn the computer off. So, it's a good idea to copy the latest version of a program out to tape as a backup.

Also, if your only storage medium is RAM, you'll have to reenter the tape reading routine laboriously through the switches (or the terminal) each time the computer power is turned on. That is a good reason for having a small program, called a bootstrap loader, kept in read-only memory. This program makes it possible to read data from the tape and then execute that data. Such a read-in program is usually somewhat larger and more powerful, so it reads in several records (perhaps using the bootstrap program as a subroutine), which make up an even larger and more sophisticated program. The effect, then, is to use one group of records to read the next

		; THIS	IS TH	HE POPULAR FI	LECTRONI	CS SUPER-		
		; SIMPI	F. MOI	VITOR. COMM	ANDS ARE			
		; D	XXXX	(DUMP FROM	A XXXX)			
		; L	XXXX	(LOAD FROM	A XXXX)			
		; G	XXXX	(GO TO XX)	(X)			
		STACK	EQU	03FFH	;YOUR S	TACK ORIGIN		
		CRLF	EQU	010.6H	;YOUR C	R, LF ROUTINE		
		WRCHR	EQU	0103H	;YOUR O	OUTPUT ROUTINE		
		RDCHR	EQU	0100H	; YOUR R	EADING ROUTINE		
		;						
		; MONIT	OR EN	TRY POINT				
0040.	212202	DEMON.	TYT	CD CENCY	THEMT	LIGE		
0040:	CD0601	FEMON :	CALL	OPLE	TCCUE	CAPPIACE DETUDN		
	3F3F		MVT	A. 121	, ISBOL	E FEED AND 2		
	CD0301		CALL	WRCHR	,	D TEED MED .		
(CD0001		CALL	RDCHR	:AWAIT	COMMAND		
I	E67F		ANI	07FH	STRIP	OFF PARITY BIT		
I	FE4C		CPI	'L'				
(CA6300		JZ	LOAD	;"LOAD"	COMMAND		
I	FE44		CPI	'D'				
(CA7400		JZ	DUMP	; "DUMP"	COMMAND		
I	FE47		CPI	'G'				
(224000	-	JNZ	PEMON	;ERROR			
		; THIS	THE T	THE "GO" COM	AND PRO	CESSOR. WE		
		; NOW E	APECI	A 10-BIT DE	STINATI	ON ADDRESS		
0055.0	CD8700	, AND :	CALL	RONUM				
BODI.	E9		PCHL	RENOM	: "GO"			
1.2		: THIS	IS TH	HE "LOAD" CON	MAND PR	OCESSOR. THE		
		; USER	IS EX	PECTED TO TY	PE IN A	16-BIT ADDRESS		
		; FOLLO	WED E	BY DATA BYTES	TO LOA	D INTO SUCCESSIVE		
		; LOCAT	IONS.	ANY NON-HE	EX CHARA	CTER SEPARATES		
		; THE B	YTES	FROM ONE AND	DTHER.	ANY BYTE THAT IS		
		; TERMI	NATEL	WITH A COLO	ON WILL	BE IGNORED.		
0063: 0	CDCD00	LOAD:	CALL	RDNR2	GET US	ER'S ADDRESS		
(CDB700		CALL	RDNUM	GET A	BXTE		
1	TESA TAGEOO		LP1	LOND+2	.CVID T	E FOLLOWED BY '.'		
	70		MOV	LUADT 5	CET IA	ST TWO HEY DICITS		
ć	12		STAX	B	STORE	THEM AWAY		
0	03		INX	B				
(236600		JMP	LOAD+3	; (GET W	/ CPU RESET)		
		; THIS	IS TH	E "DUMP" COM	MAND PR	OCESSOR.		
		; THE USER IS EXPECTED TO SUPPLY A 16-BIT						
		; STARTING ADDRESS. WHENEVER THE LEAST-SIG-						
		; NIFIC	ANT F	OUR BITS OF	THE ADD	RESS OF THE		
		; NEXT	BYTE	ARE ZERO, TH	E CARRI.	AGE IS RETURNED		
		; AND T	HE AD	DRESS IS PRI	NTED (F	OLLOWED BY COLON).		
0074: 0	CDCD00	DUMP:	CALL	RDN R2	;GET ST.	ARTING ADDRESS		
1	SOF	1.	MOV	A,C	; CHECK	TO SEE IF		
-	22200		TNZ	MORE	NO T	UST DDINT		
0	D0601		CALL	CRLF	START I	NEW LINE		
. 7	18		MOV	A.B	GET MS	B OF ADDRESS		
1	F		RAR		,			
1	F		RAR					
1	F		RAR					
1	F		RAR					
C	CDEDOO		CALL	CVTAS				
7	8		MOV	A,B	;GET 2NI	D DIGIT		
C	DEDOO		CALL	CVTAS				
1	F		PAP	A,C	GET 3RI	DIGIT		
1	F		RAR					
1	F		RAR					
î	F		RAR					
C	DEDOO		CALL	CVTAS				
7	9	1	MOV	A,C	; DO LAS	T DIGIT		
C	DEDOO		CALL	CVTAS				
3	EJA		IVM	A, ':'	; MARK AI	DDRESS SPECIALLY		
C	LUCOUL		LALL	WRCHR				

0022.	3E20 CD0301	MV CA	I A,''	FETCH BYTE TO DIMD				
OUAZ.	lF lF	RA RA	R R	FEICH BILL IO DOMP				
	1F 1F CDED00	RA RA CA	R R LL CVTAS	; ISSUE MSB				
	0A CDED00 3E20	LD CA MV	AX B LL CVTAS I A.''					
	CD0301 03 C37700	CA IN	LL WRCHR X B	; ACQUIRE NEXT CELL				
	037700	; THIS ROUTINE READS ONE OR MORE HEXADECIMAL ; DIGIT CHARACTERS ('0''9', 'A''F') IN						
		; AND ACCUMULATES A SIXTEEN-BIT NUMBER IN ; THE (H,L). EACH NEW DIGIT IS SHIFTED INTO ; THE LEAST-SIGNIFICANT FOUR BITS OF THE (H,L).						
00B7:	210000	; CONTROL ; ROUTINE RDNUM: LX	IS RETURNE ("RDHEX") I H,0	ED WHENEVER THE DEPENDENT SETS THE CARRY BIT TRUE. ;START OFF VALUE AT 0				
00C0:	CDD600 DAB700 29	CA JC RDNXT: DA	LL RDHEX RDNUM D H	;GO GET A HEX DIGIT ;AWAIT HEX DIGIT :SHIFT (H.L) LEFT 4				
	29 29 29	DA DA	D H D H D H					
	B5 6F	OR MO	A L V L,A	; PLACE NEW FOUR BITS IN				
	D8 C3C000	RC JM	P RDNXT	; THE NUMBER'S FINISHED ; GO PROCESS NEXT DIGIT				
00CD:	CDB700	; PLACES RDNR2: CA	IT INTO THE	(B,C) PAIR ;GET THE VALUE IN (H,L)				
	4D C9	MO RE	V C,L T	TN AN ASCIT CHARACTER				
		; THIS ROUTINE READS IN AN ASCII CHARACTER, ; STRIPS OFF PARITY AND EXAMINES IT FOR ; MEMBERSHIP IN THE HEX-DIGIT SET. IF IT IS						
		; A HEX-DIGIT THE A-REGISTER IS LEFT AT THE FOUR ; BIT VALUE APPROPRIATE AND THE CARRY IS CLEARED. ; ANY OTHER CHARACTER IS LEFT UNTOUCHED AND THE						
00D3:	D630 C9	RDDIG: SU	5 5E1. I '0' T	;TRANSLATE '0''9'				
00D6:	CD0001 E67F FE30	RDHEX: CA AN CP	LL RDCHR I 07FH I '0'	;***ENTRY POINT*** ;REMOVE PARITY BIT				
	D8 FE3A	RC CP	I '9'+1	CHAR LESS THAN '0' (NOT HE	X)			
	FE41 D8	CP RC	RDDIG I 'A'	; IN RANGE 09 ; BETWEEN 9 AND A				
	FE47 3F	CP CM	I 'F'+1 C					
	D8 D637 C9	RC SU RE	I 'A'-10 F	;NOT HEX CHARACTER ;TRANSLATE 'A''F'				
		; THIS ROUTINE CONVERTS A BINARY NUMBER IN THE ; LEAST-SIGNIFICANT BITS OF THE A-REGISTER TO ; AN ASCII CHARACTER REPRESENTING THE HEX VALUE						
00ED:	E60F C630	CVTAS: AN AD	I 15 I 15 I '0'	; ISOLATE FOUR BITS ; SHIFT DIGITS INTO ASCII				
	FE3A DA0301	CP. JC	I '9'+1 WRCHR	; SEE IF IT WAS 09				
	C30301	JMI	WRCHR	10 CONVERT TO AF				

group in, thus "pulling" the program in by its own bootstraps.

Using a Monitor. The ability to preserve a program for later recall is important, but it doesn't solve two major nuisances: (1) you still have to key in the program bit-by-bit the first time; and (2) every time you make an error in the program, you have to key in the changes, some of which may be traumatic and complex. One of the best ways to solve this kind of inconvenience is to provide a small monitor. A monitor is just another computer program, but one that is designed to make computer use more convenient. This program reads characters from a terminal (or a separate keyboard), with these characters specifying the bit patterns to put into memory.

The simplest monitor has three basic commands: Load, Dump and Go. A command is a single letter typed at a time when the monitor is not otherwise engaged in some activity. Typical commands are single letters like "L" for Load, "D" for Dump and "G" for Go. When you type in "L" you are directing the monitor program to accept keyboard input and load it into memory; "D" means you want to display contents of memory on your terminal or display device; "G" is your means of transferring control out of the monitor into the program you have previously loaded.

Most programmers now use the hexadecimal number system for communicating with the machine, although there are "pockets" of users of octal. Hex and octal are, of course, just shorthand notations for binary code. Hex digits allow us to specify four bits with one symbol, octal allows three. The hexadecimal digits are 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E, and F. (The letters A through F stand for decimal equivalent values 10 through 15, respectively.) The monitor, for utmost simplicity, uses only hexadecimal digits for the specification of addresses and data byte values.

Each of the command letters (L, D or G) is followed by an address that specifies where to start. For the Load command, that address is where the first byte of data from the keyboard will be stored; for Dump, it is the address from which data will begin being displayed; for Go, it is the address that is to be placed into the CPU's program counter. Whenever the Go command's address has been supplied, control is transferred to that location. Whenever the Dump command's address has been given, data displaying will begin. However, after the Load command's address, the monitor will expect more bytes (one after another) to be loaded into successive locations in memory.

A small monitor for the 8080 microprocessor that you can use as a model is shown opposite. Each command is stopped by resetting the CPU, thus returning control to the top of the monitor. Notice some error correction conventions that have been instituted to save you some time: numbers are assumed to consist of any number of hex digits but if the monitor wants an address, only the least-significant four digits are used. Likewise, for a data byte, only the least-significant two hex digits are preserved. This means that if you've made an error, just keep typing. Hex digits end with any character that is not a hex digit; most people find that the space character is the most convenient.

News Items. The extremely popular 8080, originally from Intel, is now being supplied by other semiconductor makers as well. The TI TMS8080 is identical to the original 8080, which Intel no longer makes. Intel's newer device, the 8080A, is functionally identical but has better current drive capacity. Intel has another part, the 8080A-1, that'll go faster so that AMD's 9080 (which is supposed to run 50% faster than the original Intel part) will have a competitor. So, if you are using the 8080, be sure to check the diagrams to see that your part matches the requirements.

The new MOS Technology 6501 is destined to become a popular CPU among hobbyists, if only because of its dramatically low price (\$20 at press time). The device is modelled after Motorola's 6800, although with some major differences. All of the Motorola support parts like memory I/O chips can be used with the 6501, so you can get on board quickly. The Motorola software, however, cannot be executed on the 6501 without revision.

The 6501 is capable of operation at twice the Motorola part's speed; some parts may operate three times as fast. The introduction of this part is likely to start the real price war that has been brewing in the microprocessor business. Even with the new support chip for the 8008 that Intel has announced, it seems unlikely that it can compete with the 6501 for hobbyist use.

QUICK.... what number is this?



If you have to read your microcomputer like this--bit by bit, from rows of lights--the computer's making you do its work. And if you have to use rows of toggle switches to program it, you might wonder why they call the computer a labor-saving device!

Contrast the layout of a typical pocket calculator. A key for each number and function; six easy-to-read digits. Why not design microcomputers like that?



Here they are! The modular micros from Martin Research. The keyboard programs the computer, and the bright, fullydecoded digits display data and memory addresses. A Monitor program in a PROM makes program entry easy. And, even the smallest system comes with enough RAM memory to get started!

Both the *MIKE 2* system, with the popular 8008 processor, and the 8080-based *MIKE* 3 rely on the same universal bus structure. This means that accessories--like our 450 ns 4K RAM--are compatible with these and other 8-bit CPUs. And, systems start at under \$300! For details, write for your...

FREE CATALOG!



MIKE 2 MANUAL... This looseleaf book includes full information on the *MIKE 2* system, with schematics.

Price for orders received by November 15, 1975... **\$19** Includes a certificate worth \$10 towards a modular micro system, good 90 days. (Offer valid, USA only.) After 11/15: \$25.

modular micros martin research	
--------------------------------	--

Martin Research / 3336 Commercial Ave. Northbrook, IL 60062 / (312) 498-5060 CIRCLE NO. 49 ON FREE INFORMATION CARD 103